

Instructions on use

1. Push the battery door away from the unit to open. Insert one AAA battery and replace the cover.
2. Remove the protective screen cover.
3. The unit has 3 functions on the front. MODE, ADJ, MEMORY.

To set the clock and calendar

Press and hold the MODE button for 2 seconds. You will hear a beep. The minute display will start flashing. Use the ADJ button to advance the minutes from 00 to 59. Once set, press the MODE button again. The hour display will start flashing. Use the ADJ button to advance the hours from 12AM to 11pm

Press MODE again. The default setting is 12 hour clock showing AM and PM. To set to the 24 hour clock, press ADJ.

Press MODE again. You can now set the Month and Day calendar function. After 3 seconds without activity, it returns to the clock function.

To set and cancel the alarm

Press the MODE button once (do not press and hold as before). This changes the clock to the alarm function. Press and hold the MODE button for 2 seconds and the minute display will start to flash. You will know that you are change the alarm as the word Alarm appears above the time on the display. Use the ADJ button to advance the minutes. Press the MODE button again and the hour display will start flashing. Use the ADJ button to advance the hours. After a minute, the display will revert back to the clock display. To cancel the audible alarm, press the MODE button.

4. The unit has 2 functions on the back

To change from Celsius and Fahrenheit readings, press the °C / °F button.

To reset the unit, press the RESET button once.

5. MEMORY function

Press MEMORY to display once to see the highest temperature and humidity readings since the unit was last RESET. Press again to see the minimum. Press again to return to the main display or leave for a few seconds.

Once set, can be wall mounted or free standing.

To hang. There is a small indent at the back of the unit that can hang on and exposed nail head like a picture hook pin.

Free standing. Open the leg stand to the sides of the battery compartment.